




REPAIRING PRESSFIT FLOATING FLOORS

Replacing a damaged plank – Option A




Cut the plank you wish to replace at on a short side. Lift the plank that you want to remove a few centimeters: two sides of the plank need to be lifted, and the other two need to be pressed down, to separate it from the adjacent planks.





Put the new plank into place, by inserting the tongue side under the adjacent planks and pressing it down with the help of a hand roller or slightly tap it with a rubber hammer.

Replacing a damaged plank – Option B



Lift the plank that you want to remove a few centimeters, with the help of suction cups: two sides of the plank need to be lifted, and the other two need to be pressed down, to separate it from the adjacent planks.



Put the new plank into place, by inserting the tongue side under the adjacent planks and pressing it down with the help of a hand roller or slightly tap it with a rubber hammer.